



References

## K8125A-K7125A


### RANGE STARBOLT

#### Nomenclatures


Piece	Support	Cam	Split pin	Screw	Conical spring
Quantity	x1	x1	x1	x1	x1
Visual element					

#### Assembly steps


1. Follow the drilling plan below




2. Weld the two sides marked in red below. The tab should be facing downwards.




3. Insert the screw from the front



4. Insert the conical spring



5. Screw in the cam.



6. Insert the split pin and then bend both ends to prevent it from being removed

